

# ***2006 & 2007 G/H Full-Size Van Electrical***

---

## **Overview**

### **ORGANIZATION**

This document will be updated only to reflect a major subsystem change until the next platform major electrical redesign. This document is believed to be correct until the next platform major design change. This document is organized as follows;

- Systems Operation – How it works — *Not available at time of publication.*
- Component Locator – Where it is
- Connectors & Pinouts – What it looks like, — *Not available at time of publication,* and finally,
- Subsystem Schematics – Detailed wiring and electrical schematic information.

### **WHAT'S NEW FOR THE 2006 & 2007 FULL SIZE VANS**

- The (LLY) Diesel Engine has been added as an available option.
- (UF3) Hi Idle is now an available option with the Diesel Engine only.
- The 2006 & 2007 manual includes detailed schematics for every subsystem in the vehicle.
- The (UF3) Hi Idle schematics are included in the LLY Powertrain Controls Subsystem.
- Schematic Description and Navigation instructions have been added at the beginning of Section D. This document helps you understand how the schematics are organized and how to read them.

### **Navigation**

The Table of Contents and Index items are linked to the actual page. Click on the item of interest and you'll go to the corresponding page. You can return with the "previous page" arrow in the upper center of the screen. Other links embedded in the document are hi-lighted in blue.

### **Viewing**

The size (%) control is located in the lower left corner of the screen. Click the down arrow and select "fit in window" (62%) or "actual size" (100%) for most viewing applications. You can zoom in schematic detail by selecting a larger percentage.

### **Printing**

Specific pages can be printed out. Be careful to select a print range or "current page" or all 116 pages will try to print out.

Information provided is believed to be accurate at the time of publication. GM reserves the right to change the information at any time.

## Index

### SYSTEM OPERATION INSTRUCTIONS

Not Available At Time of Publication .....A-1

### ELECTRICAL COMPONENT LOCATIONS

#### Power Distribution Centers:

|                                         |      |
|-----------------------------------------|------|
| Underhood BEC (Fuse Center) Label ..... | B-1  |
| Top View .....                          | B-2  |
| Gas .....                               | B-3  |
| Diesel .....                            | B-5  |
| Location .....                          | B-7  |
| Body Fuse Block – Label .....           | B-8  |
| Top View .....                          | B-9  |
| Description .....                       | B-10 |
| Location .....                          | B-11 |

### CONNECTOR AND PIN-OUT ILLUSTRATIONS

Not Available At Time of Publication .....C-1

### SUBSYSTEM ELECTRICAL SCHEMATICS

|                                                         |      |
|---------------------------------------------------------|------|
| Schematic Description and Navigation Instructions ..... | D-1  |
| Power Distribution (UH BEC) .....                       | D-3  |
| Power Moding .....                                      | D-10 |
| Power Distribution (Body BEC) .....                     | D-11 |
| Ground Distribution .....                               | D-16 |
| Powertrain Controls (V6 PCM) .....                      | D-23 |
| (Diesel LLY V8) .....                                   | D-33 |

|      |     |
|------|-----|
| PAGE | iii |
|------|-----|

## 2006 & 2007 G/H Full-Size Van Electrical

# 2006 & 2007 G/H Full-Size Van Electrical

## SUBSYSTEM ELECTRICAL SCHEMATICS (Continued)

|                                                     |      |
|-----------------------------------------------------|------|
| Special Equipment Options – 8S3 – Backup Alarm..... | D-92 |
| – 8S8 – Odo Security .....                          | D-93 |
| – 9B9, 9B4 – Road Speed Governor .....              | D-94 |
| – 9L0 – Computer Screen Blanking .....              | D-95 |
| – &9L4 – Mobile Radio .....                         | D-96 |
| Master System .....                                 | D-97 |

# ***2006 & 2007 G/H Full-Size Van Electrical***

---

PAGE

A-1

## ***System Operating Instructions***

***Not Available At Time of Publication***

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE B-1

## Power Distribution Centers: Underhood BEC (Fuse Center) Label

### MINI FUSES MINI-FUSIBLES

|                      |       |
|----------------------|-------|
| 1-RDO BATT           | (15A) |
| * 2-PCM BATT (G)     | (20A) |
| FOH/ECM/TCM BATT (D) | (20A) |
| 3-LT REAR STOP/TRN   | (10A) |
| 4-RT REAR STOP/TRN   | (10A) |
| 5-TRLR BCK/UP        | (10A) |
| 6-IGN O              | (10A) |
| 7-STOP LAMP          | (15A) |
| 8-REAR DEF/HTD MIR   | (20A) |
| 9-RT DRL/TRN         | (10A) |
| 10-LT DRL/TRN        | (10A) |
| 11-TBC 4             | (15A) |
| *12-FUEL PMP (G)     | (20A) |
| FUEL PMP (D)         | (15A) |
| 13-TRLR              | (30A) |
| 14-HAZRD             | (15A) |
| 15-HORN              | (15A) |
| 16-TBC 3             | (15A) |
| 17-TRLR STOP/TRN     | (15A) |
| 18-TBC 2             | (15A) |
| 19-TBC               | (10A) |
| 20-RFA               | (10A) |
| *21-ENG 2 (G)        | (10A) |
| SPARE (D)            | (10A) |
| 22-IGN E             | (10A) |
| *23-ENG 1 (G)        | (15A) |
| ENG 1 (D)            | (10A) |
| 24-TBC IGN 1         | (10A) |
| *25-SPARE (G)        | (10A) |
| FUEL HTR (D)         | (20A) |
| 26-ISRVM             | (10A) |
| 27-CRNK              | (10A) |
| 28-BTSI              | (10A) |
| 29-AUX PWR           | (20A) |

|                        |       |
|------------------------|-------|
| 30-LTR                 | (15A) |
| 31-IPC                 | (10A) |
| 32-A/C                 | (10A) |
| *33-SPARE (G)          | (10A) |
| ECM (D)                | (30A) |
| *34-CNSTR VENT SOL (G) | (10A) |
| REAR FOG LMPS (D)      | (10A) |
| *35-SPARE (G)          | (10A) |
| SPARE (D)              | (10A) |
| 36-BTSI BCK/UP         | (15A) |
| 37-AIRBAG              | (10A) |
| *38-PCM IGN 1 (G)      | (15A) |
| ECM/TCM/GLOW PLUG      | (10A) |
| CNTRL MDL IGN 1 (D)    | (10A) |
| *39-02 SNSR B (G)      | (15A) |
| SPARE (D)              | (15A) |
| *40-02 SNSR A (G)      | (15A) |
| SPARE (D)              | (15A) |
| 41-WSW                 | (15A) |
| 42-RT-LO BEAM          | (10A) |
| 43-LT-LO BEAM          | (10A) |

|                  |       |
|------------------|-------|
| 44-LT-HI BEAM    | (10A) |
| 45-RT-HI BEAM    | (10A) |
| *46-TBC ACCY (G) | (10A) |
| TBC/TCM/ACCY (D) | (10A) |
| 47-FRT WPR       | (25A) |
| *63-SPARE (G)    | (10A) |
| ECM ACT (D)      | (10A) |
| 64-SPARE         | (10A) |

### MICRO RELAYS

### MICRORELAIS


|                   |       |
|-------------------|-------|
| 53-WSW            | (10A) |
| 54-A/C            | (10A) |
| *55-SPARE (G)     | (10A) |
| REAR FOG LMPS (D) | (10A) |
| 56-LAMP-HI BEAM   | (10A) |
| 57-FUEL PMP       | (10A) |
| 58-LAMP-LO BEAM   | (10A) |
| 59-HORN           | (10A) |

### J-CASE FUSES FUSIBLES JCASE


|                  |
|------------------|
| 48-ABS/VSES(60A) |
| 49-IGN A (40A)   |
| 50-TRLR (30A)    |
| 51-BLWR (40A)    |
| 52-IGN B (40A)   |



**\*NOTE:** The function and amperage of these fuses are different, depending on vehicle content.  
(G) = GAS  
(D) = DIESEL  
**REMARQUE:** La fonction et l'intensité de ces fusibles diffèrent suivant l'équipement du véhicule.  
(G) = ESSENCE  
(D) = DIESEL



## Power Distribution Centers: Underhood BEC (Fuse Center) Top View



# 2006 & 2007 G/H Full-Size Van ELECTRICAL

PAGE **B-3**

## Power Distribution Centers: Underhood BEC (Fuse Center) Gas

| No. | Device                   | Rating | Description                                                                                                                                                                                                                                   |
|-----|--------------------------|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | RDO BATT Fuse            | 15A    | Radio (w/o UL5) or Chime Module (UL5)                                                                                                                                                                                                         |
| 2   | PCM BATT Fuse            | 20A    | Powertrain Control Module (PCM)                                                                                                                                                                                                               |
| 3   | LT REAR STOP/TRN Fuse    | 10A    | Trailer Stop/Turn Relay - Left (UF7) or C405 (Cutaway)                                                                                                                                                                                        |
| 4   | RT REAR STOP/TRN Fuse    | 10A    | Trailer Stop/Turn Relay - Right (UF7) or C405 (Cutaway)                                                                                                                                                                                       |
| 5   | TRLR BCK/UP Fuse         | 10A    | Trailer Wiring Harness (UY7) or C405 (Cutaway)                                                                                                                                                                                                |
| 6   | IGN 0 Fuse               | 10A    | Powertrain Control Module (PCM), Body Control Module (BCM), Automatic Transmission                                                                                                                                                            |
| 7   | STOP LAMP Fuse           | 15A    | Stop Lamp Switch                                                                                                                                                                                                                              |
| 8   | REAR DEF/HTD MIR Fuse    | 20A    | HVAC Control Assembly (C49/DE5/DE7)                                                                                                                                                                                                           |
| 9   | RT DRL/TRN Fuse          | 10A    | Park/Turn Signal Lamp - RF                                                                                                                                                                                                                    |
| 10  | LT DRL/TRN Fuse          | 10A    | Park/Turn Signal Lamp - LF                                                                                                                                                                                                                    |
| 11  | TBC 4 Fuse               | 15A    | Body Control Module (BCM)                                                                                                                                                                                                                     |
| 12  | FUEL PMP Fuse            | 20A    | FUEL PMP Relay                                                                                                                                                                                                                                |
| 13  | TRLR Fuse (UY7)          | 30A    | Trailer Wiring Harness                                                                                                                                                                                                                        |
| 14  | HAZRD Fuse               | 15A    | Turn Signal/Hazard Flasher Module                                                                                                                                                                                                             |
| 15  | HORN Fuse                | 15A    | HORN Relay                                                                                                                                                                                                                                    |
| 16  | TBC 3 Fuse               | 15A    | Body Control Module (BCM)                                                                                                                                                                                                                     |
| 17  | TRLR STOP/TRN Fuse (UY7) | 15A    | Trailer Stop/Turn Relay - Left and Trailer Stop/Turn Relay - Right                                                                                                                                                                            |
| 18  | TBC 2 Fuse               | 15A    | Body Control Module (BCM)                                                                                                                                                                                                                     |
| 19  | TBC Fuse                 | 10A    | Body Control Module (BCM)                                                                                                                                                                                                                     |
| 20  | RFA Fuse                 | 10A    | Remote Control Door Lock Receiver (RCDLR)                                                                                                                                                                                                     |
| 21  | ENG 2 Fuse               | 10A    | Even Fuel Injectors and Even Ignition Coils (4.8L/5.3L/6.0L) or Even Fuel Injectors and Ignition Coil (4.3L)                                                                                                                                  |
| 22  | IGN E Fuse               | 10A    | Stop Lamp Switch and A/C Relay                                                                                                                                                                                                                |
| 23  | ENG 1 Fuse               | 15A    | Odd Fuel Injectors, Odd Ignition Coils, EVAP Canister Purge Solenoid Valve, MAF/IAT Sensor, PNP Switch (4.8L/5.3L/6.0L) or Odd Fuel Injectors, Ignition Control Module, EVAP Canister Purge Solenoid Valve, MAF/IAT Sensor, PNP Switch (4.3L) |
| 24  | TBC IGN 1 Fuse           | 10A    | Body Control Module (BCM)                                                                                                                                                                                                                     |
| 25  | SPARE Fuse               | —      | Not Used                                                                                                                                                                                                                                      |
| 26  | ISRVF Fuse               | 10A    | Inside Rearview Mirror (DF5)                                                                                                                                                                                                                  |
| 27  | CRNK Fuse                | 10A    | Powertrain Control Module (PCM)                                                                                                                                                                                                               |
| 28  | BTSI Fuse                | 10A    | Stop Lamp Switch                                                                                                                                                                                                                              |
| 29  | AUX PWR Fuse             | 20A    | Auxiliary Power Outlet 2                                                                                                                                                                                                                      |
| 30  | LTR Fuse                 | 15A    | Cigar Lighter/Auxiliary Power Outlet 1 and Data Link Connector (DLC)                                                                                                                                                                          |
| 31  | IPC Fuse                 | 10A    | Instrument Panel Cluster (IPC)                                                                                                                                                                                                                |
| 32  | A/C Fuse                 | 10A    | A/C Relay                                                                                                                                                                                                                                     |
| 33  | SPARE Fuse               | —      | Not Used                                                                                                                                                                                                                                      |
| 34  | CNSTR VENT SOL Fuse      | 10A    | EVAP Canister Vent Solenoid Valve and SPARE Relay                                                                                                                                                                                             |

*(continued on next page)*

# 2006 & 2007 G/H Full-Size Van ELECTRICAL

## ***Power Distribution Centers: Underhood BEC (Fuse Center) Gas (continued)***

| No. | Device                   | Rating | Description                                                                                                                                                     |
|-----|--------------------------|--------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 35  | SPARE Fuse               | —      | Not Used                                                                                                                                                        |
| 36  | BTSI BCK/UP Fuse         | 15A    | Park/Neutral Position (PNP) Switch                                                                                                                              |
| 37  | AIRBAG Fuse              | 10A    | PPS Module and Inflatable Restraint PASSENGER AIR BAG ON/OFF Indicator (Light Duty w/o YF7), Inflatable Restraint I/P Module Disable Switch (Heavy Duty), SDM   |
| 38  | PCM IGN 1 Fuse           | 15A    | Powertrain Control Module (PCM), Cruise Control Module (CCM) - w/o JL4 or Throttle Actuator Control (TAC) Module and Steering Wheel Speed/Position Sensor - JL4 |
| 39  | O2 SNSR B Fuse           | 15A    | HO2S Bank 1 Sensor 2 and Bank 2 Sensor 2                                                                                                                        |
| 40  | O2 SNSR A Fuse           | 15A    | HO2S Bank 1 Sensor 1 and Bank 2 Sensor 1                                                                                                                        |
| 41  | WSW Fuse                 | 15A    | WSW Relay                                                                                                                                                       |
| 42  | RT-LO BEAM Fuse          | 10A    | Headlamp Low Beam - Right (Composite) or Headlamp - Right (Sealed)                                                                                              |
| 43  | LT-LO BEAM Fuse          | 10A    | Headlamp Low Beam - Left (Composite) or Headlamp - Left (Sealed)                                                                                                |
| 44  | LT-HI BEAM Fuse          | 10A    | Headlamp High Beam - Left (Composite) or Headlamp - Left (Sealed)                                                                                               |
| 45  | RT-HI BEAM Fuse          | 10A    | Headlamp High Beam - Right (Composite) or Headlamp - Right (Sealed)                                                                                             |
| 46  | TBC ACCY Fuse            | 10A    | Body Control Module (BCM)                                                                                                                                       |
| 47  | FRT WPR Fuse             | 25A    | Windshield Wiper Motor                                                                                                                                          |
| 48  | ABS/VSES Fuse            | 60A    | Electronic Brake Control Module (EBCM)                                                                                                                          |
| 49  | IGN A Fuse               | 40A    | STRTR Relay and Ignition Switch                                                                                                                                 |
| 50  | TRLR Fuse (UY7)          | 30A    | Trailer Wiring Harness                                                                                                                                          |
| 51  | BLWR Fuse                | 40A    | Blower Motor Resistor Assembly                                                                                                                                  |
| 52  | IGN B Fuse               | 40A    | Ignition Switch                                                                                                                                                 |
| 53  | WSW Relay                | —      | Windshield Wiper Motor                                                                                                                                          |
| 54  | A/C Relay                | —      | A/C Compressor Clutch                                                                                                                                           |
| 55  | SPARE Relay              | —      | Not Used                                                                                                                                                        |
| 56  | LAMP-HI BEAM Relay       | —      | RT-HI BEAM and LT-HI BEAM Fuses                                                                                                                                 |
| 57  | FUEL PMP Relay           | —      | Fuel Pump                                                                                                                                                       |
| 58  | LAMP-LO BEAM Relay       | —      | RT-LO BEAM and LT-LO BEAM Fuses                                                                                                                                 |
| 59  | HORN Relay               | —      | Horn Assembly                                                                                                                                                   |
| 60  | PWR SEAT Circuit Breaker | 30A    | Seat Adjuster Switch - Driver (AG1) and Seat Adjuster Switch - Passenger (AG2)                                                                                  |
| 61  | STRTR Relay              | —      | Starter                                                                                                                                                         |
| 62  | SPARE Relay              | —      | Not Used                                                                                                                                                        |
| 63  | SPARE Fuse               | —      | Not Used                                                                                                                                                        |
| 64  | SPARE Fuse               | —      | Not Used                                                                                                                                                        |
| 65  | 125A Fuse                | 125A   | Fuse Block - Body                                                                                                                                               |

# 2006 & 2007 G/H Full-Size Van Electrical

## Power Distribution Centers: Underhood BEC (Fuse Center) Diesel

| No. | Device                   | Rating | Description                                                                                                     |
|-----|--------------------------|--------|-----------------------------------------------------------------------------------------------------------------|
| 1   | RDO BATT Fuse            | 15A    | Radio (w/o UL5) or Chime Module (UL5)                                                                           |
| 2   | FOH/ECM/TCM BATT Fuse    | 20A    | Engine Control Module (ECM), Transmission Control Module (TCM), Coolant Heater (K08)                            |
| 3   | LT REAR STOP/TRN Fuse    | 10A    | Trailer Stop/Turn Relay - Left (UY7) or C405 (Cutaway)                                                          |
| 4   | RT REAR STOP/TRN Fuse    | 10A    | Trailer Stop/Turn Relay - Right (UY7) or C405 (Cutaway)                                                         |
| 5   | TRLR BCK/UP Fuse         | 10A    | Trailer Wiring Harness (UY7) or C405 (Cutaway)                                                                  |
| 6   | IGN 0 Fuse               | 10A    | Engine Control Module (ECM), Body Control Module (BCM), Automatic Transmission, Glow Plug Control Module (GPCM) |
| 7   | STOP LAMP Fuse           | 15A    | Stop Lamp Switch                                                                                                |
| 8   | REAR DEF/HTD MIR Fuse    | 20A    | HVAC Control Assembly (C49/DE5/DE7)                                                                             |
| 9   | RT DRL/TRN Fuse          | 10A    | Park/Turn Signal Lamp - RF                                                                                      |
| 10  | LT DRL/TRN Fuse          | 10A    | Park/Turn Signal Lamp - LF                                                                                      |
| 11  | TBC 4 Fuse               | 15A    | Body Control Module (BCM)                                                                                       |
| 12  | FUEL PMP Fuse            | 15A    | FUEL PMP Relay                                                                                                  |
| 13  | TRLR Fuse (UY7)          | 30A    | Trailer Wiring Harness                                                                                          |
| 14  | HAZRD Fuse               | 15A    | Turn Signal/Hazard Flasher Module                                                                               |
| 15  | HORN Fuse                | 15A    | HORN Relay                                                                                                      |
| 16  | TBC 3 Fuse               | 15A    | Body Control Module (BCM)                                                                                       |
| 17  | TRLR STOP/TRN Fuse (UY7) | 15A    | Trailer Stop/Turn Relay - Left and Trailer Stop/Turn Relay - Right                                              |
| 18  | TBC 2 Fuse               | 15A    | Body Control Module (BCM)                                                                                       |
| 19  | TBC Fuse                 | 10A    | Body Control Module (BCM)                                                                                       |
| 20  | RFA Fuse                 | 10A    | Remote Control Door Lock Receiver (RCDLR)                                                                       |
| 21  | SPARE Fuse               | —      | Not Used                                                                                                        |
| 22  | IGN E Fuse               | 10A    | Stop Lamp Switch and A/C Relay                                                                                  |
| 23  | ENG 1 Fuse               | 10A    | MAF/IAT Sensor and PNP Switch                                                                                   |
| 24  | TBC IGN 1 Fuse           | 10A    | Body Control Module (BCM)                                                                                       |
| 25  | FUEL HTR Fuse            | 20A    | Fuel Heater                                                                                                     |
| 26  | ISRVF Fuse               | 10A    | Inside Rearview Mirror (DF5)                                                                                    |
| 27  | CRNK Fuse                | 10A    | Engine Control Module (ECM)                                                                                     |
| 28  | BTSI Fuse                | 10A    | Stop Lamp Switch                                                                                                |
| 29  | AUX PWR Fuse             | 20A    | Auxiliary Power Outlet 2                                                                                        |
| 30  | LTR Fuse                 | 15A    | Cigar Lighter/Auxiliary Power Outlet 1 and Data Link Connector (DLC)                                            |
| 31  | IPC Fuse                 | 10A    | Instrument Panel Cluster (IPC)                                                                                  |
| 32  | A/C Fuse                 | 10A    | A/C Relay                                                                                                       |
| 33  | ECM Fuse                 | 30A    | ECM Relay                                                                                                       |
| 34  | REAR FOG LMPS Fuse (T79) | 10A    | REAR FOG LMPS Relay                                                                                             |
| 35  | SPARE Fuse               | —      | Not Used                                                                                                        |


(continued on next page)

# 2006 & 2007 G/H Full-Size Van Electrical

## ***Power Distribution Centers: Underhood BEC (Fuse Center) Diesel (continued)***

| No. | Device                                    | Rating | Description                                                                                     |
|-----|-------------------------------------------|--------|-------------------------------------------------------------------------------------------------|
| 36  | BTSI BCK/UP Fuse                          | 15A    | Park/Neutral Position (PNP) Switch                                                              |
| 37  | AIRBAG Fuse                               | 10A    | Inflatable Restraint I/P Module Disable Switch and SDM                                          |
| 38  | ECM/TCM/GLOW PLUG<br>CNTRL MDL IGN 1 Fuse | 10A    | Engine Control Module (ECM), Glow Plug Control Module (GPCM), Transmission Control Module (TCM) |
| 39  | SPARE Fuse                                | —      | Not Used                                                                                        |
| 40  | SPARE Fuse                                | —      | Not Used                                                                                        |
| 41  | WSW Fuse                                  | 15A    | WSW Relay                                                                                       |
| 42  | RT-LO BEAM Fuse                           | 10A    | Headlamp Low Beam Right (Composite) or Headlamp - Right (Sealed)                                |
| 43  | LT-LO BEAM Fuse                           | 10A    | Headlamp Low Beam Left (Composite) or Headlamp - Left (Sealed)                                  |
| 44  | LT-HI BEAM Fuse                           | 10A    | Headlamp High Beam Left (Composite) or Headlamp - Left (Sealed)                                 |
| 45  | RT-HI BEAM Fuse                           | 10A    | Headlamp High Beam Right (Composite) or Headlamp - Right (Sealed)                               |
| 46  | TBC/TCM ACCY Fuse                         | 10A    | Body Control Module (BCM) and Transmission Control Module (TCM)                                 |
| 47  | FRT WPR Fuse                              | 25A    | Windshield Wiper Motor                                                                          |
| 48  | ABS/VSES Fuse                             | 60A    | Electronic Brake Control Module (EBCM)                                                          |
| 49  | IGN A Fuse                                | 40A    | STRTR Relay and Ignition Switch                                                                 |
| 50  | TRLR Fuse (UY7)                           | 30A    | Trailer Wiring Harness                                                                          |
| 51  | BLWR Fuse                                 | 40A    | Blower Motor Resistor Assembly                                                                  |
| 52  | IGN B Fuse                                | 40A    | Ignition Switch                                                                                 |
| 53  | WSW Relay                                 | —      | Windshield Wiper Motor                                                                          |
| 54  | A/C Relay                                 | —      | A/C Compressor Clutch                                                                           |
| 55  | REAR FOG LMPS Relay (T79)                 | —      | Rear Fog Lamps                                                                                  |
| 56  | LAMP-HI BEAM Relay                        | —      | RT-HI BEAM and LT-HI BEAM Fuses                                                                 |
| 57  | FUEL PMP Relay                            | —      | Fuel Prime Pump                                                                                 |
| 58  | LAMP-LO BEAM Relay                        | —      | RT-LO BEAM and LT-LO BEAM Fuses                                                                 |
| 59  | HORN Relay                                | —      | Horn Assembly                                                                                   |
| 60  | PWR SEAT Circuit Breaker                  | 30A    | Seat Adjuster Switch - Driver (AG1) and Seat Adjuster Switch - Passenger (AG2)                  |
| 61  | STRTR Relay                               | —      | Starter                                                                                         |
| 62  | ECM Relay                                 | —      | ECM ACT Fuse and Engine Control Module (ECM)                                                    |
| 63  | ECM ACT Fuse                              | 10A    | Engine Control Module (ECM)                                                                     |
| 64  | SPARE Fuse                                | —      | Not Used                                                                                        |
| 65  | 125A Fuse                                 | 125A   | Fuse Block - Body                                                                               |

## Power Distribution Centers: Underhood BEC (Fuse Center) Location



- (1) Fuse Block Underhood – C7
- (2) Fuse Block Underhood – C5
- (3) Fuse Block Underhood – C6
- (4) Fuse Block Underhood
- (5) Fuse Block Underhood – C4
- (6) Fuse Block Underhood – C1

- (7) Fuse Block Underhood – C2
- (8) Fuse Block Underhood – C10
- (9) Fuse Block Underhood – C3
- (10) Fuse Block Underhood – C8 (UY7)
- (11) Fuse Block Underhood – C9

## Power Distribution Centers: Body Fuse Block – Label

### MINI FUSE

|                      |       |
|----------------------|-------|
| 1 – SPARE            |       |
| 2 – OSRVM            | (10A) |
| 3 – CSTY LAMP/SEO    | (15A) |
| 4 – LT REAR STOP/TRN | (10A) |
| 5 – REAR DR LCKS     | (10A) |
| 6 – RT REAR STOP/TRN | (10A) |
| 7 – DR LCKS          | (10A) |
| 8 – STOP/CHMSL       | (10A) |
| 9 – HVAC 1           | (10A) |
| 10 – HVAC            | (20A) |
| 11 – BRK             | (10A) |
| 12 – HTD MIR/DEFOG   | (30A) |
| 13 – REAR BLWR       | (30A) |
| 14 – DRV PWR TRN MIR | (10A) |
| 15 – DR/LCK          | (20A) |
| 16 – UPFTR PRK LAMPS | (10A) |
| 17 –                 |       |
| 18 – LT REAR PRK     | (10A) |
| 19 – PASS TRN MIR    | (10A) |
| 20 – RT REAR PRK     | (10A) |
| 21 – TRLR PRK        | (15A) |
| 22 – FRT PRK         | (10A) |

### J-CASE FUSE


|            |              |
|------------|--------------|
| 32 – AUX 1 | (50A OR 60A) |
| 33 – AUX 2 | (50A OR 20A) |

### MICRO RELAY

|                  |
|------------------|
| 26 – CTSY LAMP   |
| 27 – CARGO UNLCK |
| 28 – DRV UNLCK   |
| 29 – PARK LAMP   |
| 30 – DR/LCKS     |
| 31 – PASS UNLCK  |

### MINI RELAY

|                 |
|-----------------|
| 23 – RAP        |
| 25 – REAR DEFOG |




### HIGH CURRENT RELAY

|          |
|----------|
| 24 – AUX |
|----------|

### CIRCUIT BREAKER

|               |
|---------------|
| 34 – PWR WNDW |
|---------------|

## Power Distribution Centers: Body Fuse Block – Top View




# 2006 & 2007 G/H Full-Size Van Electrical

## Power Distribution Centers: Body Fuse Block – Description

| No. | Device                                       | Rating     | Description                                                                                                                                                                                                          |
|-----|----------------------------------------------|------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | SPARE Fuse                                   | —          | Not Used                                                                                                                                                                                                             |
| 2   | OSRVM Fuse (DE5/DE7)                         | 10A        | Outside Rearview Mirror Switch                                                                                                                                                                                       |
| 3   | CTSY LAMP/SEO Fuse (YF7)                     | 15A        | CTSY LAMP Relay                                                                                                                                                                                                      |
| 4   | LT REAR STOP/TRN Fuse                        | 10A        | Tail/Stop and Turn Signal Lamp - Left                                                                                                                                                                                |
| 5   | REAR DR LCKS Fuse<br>(Passenger/Cargo w/AU3) | 10A        | CARGO UNLCK Relay                                                                                                                                                                                                    |
| 6   | RT REAR STOP/TRN Fuse                        | 10A        | Tail/Stop and Turn Signal Lamp - Right                                                                                                                                                                               |
| 7   | DR LCKS Fuse (AU3)                           | 10A        | DRV UNLCK Relay                                                                                                                                                                                                      |
| 8   | STOP/CHMSL Fuse                              | 10A        | Center High Mounted Stop Lamp (CHMSL) - Passenger/Cargo, Cruise Control Module (CCM) - Gas w/K34, Throttle Actuator Control Module (TCM) - JL4, Transmission Control Module and Engine Control Module (ECM) - Diesel |
| 9   | HVAC 1 Fuse                                  | 10A        | HVAC Control Assembly (C49/DE5/DE7), Air Temperature Actuator, HVAC Control Processor, Auxiliary Blower Motor Relays & Air/Mode Actuators (C69)                                                                      |
| 10  | HVAC Fuse                                    | 20A        | HVAC Control Assembly, Vacuum Pump - Diesel                                                                                                                                                                          |
| 11  | BRK Fuse                                     | 10A        | Electronic Brake Control Module (EBCM), High Idle Switch - UF3, Traction Control Switch - JL4                                                                                                                        |
| 12  | HTD MIR/DEFOG Fuse (C49)                     | 30A        | REAR DEFOG Relay                                                                                                                                                                                                     |
| 13  | REAR BLWR Fuse                               | 30A        | Low/Med/High Speed Blower Motor Relays - Auxiliary (C36/C69) or C409 (ENC)                                                                                                                                           |
| 14  | DRV PWR TRN MIR Fuse                         | 10A        | Outside Rearview Mirror - Driver (DE7) or C405 (Cutaway)                                                                                                                                                             |
| 15  | DR LCK Fuse (AU3)                            | 20A        | DR LCKS Relay                                                                                                                                                                                                        |
| 16  | UPFTR PRK LAMPS Fuse (YF7)                   | 10A        | C320 - Upfitter Wiring Harness                                                                                                                                                                                       |
| 17  | —                                            | —          | Not Used                                                                                                                                                                                                             |
| 18  | LT REAR PRK Fuse                             | 10A        | Tail/Stop and Turn Signal Lamp - Left and License Lamp                                                                                                                                                               |
| 19  | PASS TRN MIR Fuse                            | 10A        | Outside Rearview Mirror - Passenger (DE7) and C405 (Cutaway)                                                                                                                                                         |
| 20  | RT REAR PRK Fuse                             | 10A        | Tail/Stop and Turn Signal Lamp - Right                                                                                                                                                                               |
| 21  | TRLR PRK Fuse                                | 15A        | Trailer Wiring Harness - (UY7) or C405 (Cutaway)                                                                                                                                                                     |
| 22  | FRT PRK Fuse                                 | 10A        | Inflatable Restraint I/P Module Disable Switch, Park/Turn signal Lamps - LF/RF and Marker Lamps - LF/RF                                                                                                              |
| 23  | RAP Relay (A31)                              | —          | PWR WNDW Circuit Breaker                                                                                                                                                                                             |
| 24  | AUX Relay (YF7)                              | —          | Upfitter Wiring Harness - C222 and C321                                                                                                                                                                              |
| 25  | REAR DEFOG Relay (C49)                       | —          | Rear Window Defogger Grid - Left/Right                                                                                                                                                                               |
| 26  | CTSY LAMP Relay (YF7)                        | —          | C320, C405 (Cutaway)                                                                                                                                                                                                 |
| 27  | CARGO UNLCK Relay<br>(Passenger/Cargo w/AU3) | —          | Door Latch Assembly - Cargo                                                                                                                                                                                          |
| 28  | DRV UNLCK Relay (AU3)                        | —          | Door Latch Assembly - Driver                                                                                                                                                                                         |
| 29  | PARK LAMP Relay                              | —          | FRT PRK, LT REAR PRK, RT REAR PRK, TRLR PRK and UPFTR PRK LAMPS Fuses                                                                                                                                                |
| 30  | DR/LCKS Relay (AU3)                          | —          | Door Latch Assembly - Driver/Passenger/Cargo and Door Lock Actuators - LR/RR                                                                                                                                         |
| 31  | PASS UNLCK Relay (AU3)                       | —          | Door Latch Assembly - Passenger and Door Lock Actuators - LR/RR                                                                                                                                                      |
| 32  | AUX 1 Fuse (JL4/YF7)                         | 50A<br>60A | Upfitter Wiring Harness - C222, C321 (YF7)<br>EBCM (JL4)                                                                                                                                                             |
| 33  | AUX 2 Fuse (SEO/YF7)                         | 50A<br>20A | AUX Relay (YF7)<br>AUX Relay (SEO)                                                                                                                                                                                   |
| 34  | PWR WNDW Circuit Breaker (A31)               | 25A        | Window Switch - Driver/Passenger                                                                                                                                                                                     |

## Power Distribution Centers: Body Fuse Block – Location



- (1) Fuse Block Body – Cover
- (2) Fuse Block Body – C4 (YF7)
- (3) Fuse Block Body – C3
- (4) Fuse Block Body – C1

- (5) Inflatable Restraint Sensing and Diagnostic Module (SDM)
- (6) Fuse Block Body – C2
- (7) Fuse Block Body – C5 (YF7)

## ***Connectors and Pinnouts***

***Not Available At Time of Publication***

## Schematic Description and Navigation Instructions

### Background

The Schematics included in this document are part of GM's IVED drawing system. These are the official drawings used to develop vehicle programs, produce wire harnesses and develop service documentation. The following information is offered to help you understand how they are organized and how to use them.

### Organization

It's impossible to put all the information on only one drawing. The vehicle is broken down by subsystem. The schematics are organized by subsystem number not by name. That's why the index doesn't follow an alphabetical order of the subsystems.

A number has been added on the bottom right of each page that indicates the subsystem number, revision level, and page number.

Example:

The first sheet is **826010a\_004\_01** (see page D-3)

**826010a\_004\_01** The "826010a" is the Object ID on the drawing and represents the subsystem.

**826010a\_004\_01** The "010" represents the subsystem, in this case Power Distribution.  
Other examples are "014" for Ground Distribution and "020" for Engine Controls.

**826010a\_004\_01** The "a" represents the first or only drawing for that subsystem. In this case multiple Power Distribution Schematics are included. "a" is for Underhood Bussed Electrical Center (UH BEC), "b" for Power Moding, and "c" for the Body BEC.

**826010a\_004\_01** The "004" represents the revision level and is not important for most of your needs.

**826010a\_004\_01** The "01" represents panel set one on the schematic and indicates the page number. This Schematic has seven pages for example.

### Navigation

Every wire in the vehicle is given a unique circuit number. These numbers are indicated on the schematics in bold type next to the wire. An entire subsystem usually can't be represented by only one page. How do you determine where a wire is connected to once it leaves the page? Either the signal is connected somewhere else in the same subsystem or it goes to another subsystem.

*(continued on next page)*

(Overview — continued from previous page)

## Arrows and “Home” Plates

An Arrow is used to indicate that the signal stays within the same subsystem. The schematic indicates the circuit number and (page #) next to the arrow. A pointed arrow ( → ) points to where it's going to. A receiving arrow ( ➤ ) shows what page it came from.

A “Baseball Home Plate”  or  indicates that the signal goes to another subsystem.

Example:

A  is shown on the upper right of the first schematic Power Distribution 826010a\_004\_01. (see page D-3)

This is an 842 circuit and the “baseball plate” indicates which subsystem it goes to. It is marked:

(PWR DIST)

BATTERY

The inside of the “plate” is marked Bbec for Body BEC.

The other end of the signal is shown in Body BEC subsystem drawing 10c. (see page D-11). Multiple “baseball plates” are shown so you look for the 842 circuit to identify the proper circuit. You can find the location of the subsystem by checking the index or from the Master System drawing. The Master System drawing also provides the Subsystem (Object ID) number shown on the bottom right of each schematic (xxxx010c\_xx\_xx on page D-11).


## Other Information

Other information on the schematics are wire color and size. The size is shown in square mm. Connector information is indicated for devices. Terminal assignments are shown for devices. The connector PN is for the harness end not the device.

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-3

## Power Distribution (UH BEC)



**PAGE** **D-4**

## UNDERHOOD BEC




| REVISION | STAGE | VERSION | LAST CHANGED BY |
|----------|-------|---------|-----------------|
| 004      | X     |         |                 |

ORGANIZATION  
GMT610  
12:06:00 pm Panel Set: 2


**PAGE** **D-5**

## UNDERHOOD BEC



**PAGE** **D-6**

## UNDERHOOD BEC



**PAGE** **D-7**

## UNDERHOOD BEC




**PAGE** **D-8**

## UNDERHOOD BEC



**PAGE** **D-9**


## UNDERHOOD BEC



# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-10

## Power Moding



Power Moding

GMT610 06 G\_Van  
Panel Set: 1 schematic sheet1 \$ 4

OBJECT ID  
826010b

REVISION  
002

STAGE  
X

VERSION  
LAST CHANGED BY

Monday, December 1, 2003

ORGANIZATION  
GMT610

5:08:39 pm Panel Set: 1

IVEDWORK/826010b\_002




**PAGE** **D-12**

[illegible]

# 2006 & 2007 G/H Full-Size Van ELECTRICAL

PAGE D-13

## Power Distribution (Body BEC)



**PAGE** **D-14**

## BODY BEC



**PAGE** **D-15**

Power Distribution (Body BEC)

OBJECT ID: 826010c

REVISION: 004

STAGE: X

VERSION: 004

LAST CHANGED BY: GMT610

ORGANIZATION: GMT610

Panel Set: 5

sheet1

8

IVEDWORK/826010c\_004

Tuesday, September 14, 2004


12:40:08 pm

Panel Set: 5

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-16

## Ground Distribution



Ground Distribution  
GMT610  
Panel Set: 1

OBJECT ID  
826014a

REVISION  
004

STAGE  
X

VERSION  
LAST CHANGED BY

Tuesday, September 14, 2004


ORGANIZATION  
GMT610

11:33:06 am Panel Set: 1

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-17

## Ground Distribution



Ground Distribution  
 GMT610 06 G\_Van  
 Panel Set: 2 schematic sheet1 \$ 7

OBJECT ID  
 826014a

REVISION STAGE VERSION LAST CHANGED BY  
 004 X

Tuesday, September 14, 2004


ORGANIZATION  
 GMT610  
 Panel Set: 2

IVEDWORK/826014a\_004

11:33:06 am

**PAGE** **D-18**

## Ground Distribution



**PAGE** **D-19**

**(350 & 351 GROUNDS)**



OBJECT ID  
826014a

REVIS  
004

STAGE  
X

VERSIO

LAST CHANGED BY

Tuesday, September 14, 2004


ORGANIZATION  
**GMT610**

Panel Set: 4

# 2006 & 2007 G/H Full-Size Van ELECTRICAL

PAGE D-20

## Ground Distribution



**PAGE** **D-21**


[illegible]

**PAGE** **D-22**

## Ground Distribution




**NOTE:**  
FOR 2003 SOP THE 850  
GROUND IS LOCATED ON  
THE RIGHT AND 1050 IS  
LOCATED ON THE LEFT.



## Powertrain Controls (V6 PCM)

NOTE:  
9L0 IS NOT AVAILABLE  
WITH K34



Powertrain Controls (v6 Pcm)

GMT610

06 G\_Van

&LU3

826020a

IVEDWORK/826020a\_002

REVISION

002

STAGE

X

VERSION

LAST CHANGED BY

Monday, December 1, 2003

ORGANIZATION

GMT610


5:22:29 pm

Panel Set: 1

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-24

## Powertrain Controls (V6 PCM)



Powertrain Controls (v6 Pcm)

GMT610 06 G\_Van &LU3  
Panel Set: 2 schematic sheet1

OBJECT ID  
826020a

8

SIVEDWORK/826020a\_002

REVISION  
002

STAGE  
X

VERSION LAST CHANGED BY

Monday, December 1, 2003

ORGANIZATION

GMT610

5:22:29 pm Panel Set: 2

**PAGE** **D-25**

**Powertrain Controls (v6 Pcm)**

**GMT610**

Panel Set: 3

06 G. Van

sheet1

8

OBJECT ID

826020a

REVISION

002

STAGE

X

VERSION

LAST CHANGED BY

ORGANIZATION

GMT610

5/22/29 pm


Panel Set: 3

Monday, December 1, 2003

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-26

## Powertrain Controls (V6 PCM)



Powertrain Controls (v6 Pcm)

GMT610 06 G\_Van &LU3  
Panel Set: 4 schematic sheet1

OBJECT ID  
826020a

8

\$IVEDWORK/826020a\_002

REVISION  
002

STAGE  
X

VERSION LAST CHANGED BY

Monday, December 1, 2003


ORGANIZATION  
GMT610

5:22:29 pm Panel Set: 4

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-27

## Powertrain Controls (V6 PCM)



Powertrain Controls (v6 Pcm)

GMT610  
Panel Set: 5

06 G\_Van  
schematic

&LU3  
sheet1

S 8

OBJECT ID  
826020a

IVEDWORK/826020a\_002

REVISION  
002

STAGE  
X

VERSION

LAST CHANGED BY

Monday, December 1, 2003


ORGANIZATION  
GMT610

5:22:29 pm Panel Set: 5

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-28

## Powertrain Controls (V6 PCM)



Powertrain Controls (v6 Pcm)

GMT610 06 G\_Van &LU3  
Panel Set: 6 schematic sheet1 S 8

OBJECT ID  
826020a

IVEDWORK/826020a\_002

REVISION  
002

STAGE  
X

VERSION  
LAST CHANGED BY  
Monday, December 1, 2003

ORGANIZATION  
GMT610

5:22:29 pm Panel Set: 6

**PAGE** **D-29**

**Powertrain Controls (v6 Pcm)**

**OBJECT ID**  
826020a

**REVISION**  
002

**STAGE**  
X

**VERSION**  
LAST CHANGED BY

**ORGANIZATION**  
GMT610

**Panel Set: 7**  
schematic sheet1 S 8


**IVEDWORK/826020a\_002**  
Monday, December 1, 2003

**5:22:29 pm**  
Panel Set: 7

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-30

## Powertrain Controls (V6 PCM)



Powertrain Controls (v6 Pcm)

GMT610 06 G\_Van &LU3  
Panel Set: 8 schematic sheet1 S 8

OBJECT ID  
826020a

REVISION  
002

STAGE  
X

VERSION  
LAST CHANGED BY

Monday, December 1, 2003

ORGANIZATION  
GMT610


5:22:29 pm Panel Set: 8

IVEDWORK/826020a\_002

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-31

## Powertrain Controls (V6 PCM)



Powertrain Controls (v6 Pcm)

GMT610 06 G\_Van &LU3  
Panel Set: 9 schematic sheet1

OBJECT ID  
826020a

IVEDWORK/826020a\_002

REVISION  
002

STAGE  
X

VERSION  
LAST CHANGED BY


Monday, December 1, 2003

ORGANIZATION  
GMT610

5:22:29 pm Panel Set: 9

# 2006 & 2007 G/H Full-Size Van Electrical


## Powertrain Controls (V6 PCM)



**PAGE** **D-33**

[illegible]

## Powertrain Controls (Diesel LLY V8)



Powertrain Controls (diesel Lly V8)

GMT610 06 G\_Van  
Panel Set: 2 schematic sheet1

OBJECT ID  
826020c

REVISION  
005

STAGE  
X

VERSION LAST CHANGED BY

Tuesday, September 14, 2004


ORGANIZATION  
GMT610

6:56:54 pm

# 2006 & 2007 G/H Full-Size Van ELECTRICAL

PAGE D-35

## Powertrain Controls (Diesel LLY V8)



Powertrain Controls (diesel Lly V8)  
GMT610 06 G\_Van  
Panel Set: 3 schematic sheet1 \$ 19

OBJECT ID  
826020c

REVISION  
005

STAGE  
X

VERSION  
LAST CHANGED BY

Tuesday, September 14, 2004

ORGANIZATION  
GMT610


6:56:54 pm

IVEDWORK/826020c\_005

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-36

## Powertrain Controls (Diesel LLY V8)



**PRELIMINARY**

Powertrain Controls (diesel Lly V8)  
GMT610 06 G\_Van  
Panel Set: 4 schematic sheet1 \$ 19

OBJECT ID  
826020c

REVISION 005  
STAGE X  
VERSION  
LAST CHANGED BY

Tuesday, September 14, 2004


ORGANIZATION  
GMT610

6:56:54 pm

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-37

## Powertrain Controls (Diesel LLY V8)



Powertrain Controls (diesel Lly V8)

OBJECT ID  
826020c

REVISION STAGE VERSION LAST CHANGED BY  
005 X

ORGANIZATION  
GMT610

GMT610  
Panel Set: 5

06 G\_Van  
schematic

sheet1

S 19

IVEDWORK/826020c\_005


Tuesday, September 14, 2004

6:56:54 pm

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-38

## Powertrain Controls (Diesel LLY V8)



Powertrain Controls (diesel Lly V8)

GMT610 06 G\_Van  
Panel Set: 6 schematic sheet1

OBJECT ID  
826020c

\$ 19

IVEDWORK/826020c\_005

REVISION  
005

STAGE  
X

VERSION LAST CHANGED BY

Tuesday, September 14, 2004


ORGANIZATION  
GMT610

6:56:54 pm

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-39

## Powertrain Controls (Diesel LLY V8)



Powertrain Controls (diesel Lly V8)

GMT610  
Panel Set: 7

06 G\_Van  
schematic

sheet1

\$ 19

OBJECT ID  
826020c

IVEDWORK/826020c\_005

REVISION  
005

STAGE  
X

VERSION  
LAST CHANGED BY

Tuesday, September 14, 2004

ORGANIZATION  
GMT610

6:56:54 pm



# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-41

## Powertrain Controls (Diesel LLY V8)



Powertrain Controls (diesel Lly V8)

GMT610 06 G\_Van  
Panel Set: 9 schematic sheet1

OBJECT ID  
826020c

\$ 19

IVEDWORK/826020c\_005

REVISION  
005

STAGE  
X

VERSION LAST CHANGED BY

Tuesday, September 14, 2004


ORGANIZATION  
GMT610

6:56:54 pm

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-42

## Powertrain Controls (Diesel LLY V8)



Powertrain Controls (diesel Lly V8)  
GMT610 06 G\_Van  
Panel Set: 10 schematic sheet1 \$ 19

OBJECT ID  
826020c

REVISION  
005

STAGE  
X

VERSION

LAST CHANGED BY

Tuesday, September 14, 2004


ORGANIZATION  
GMT610

6:56:54 pm

IVEDWORK/826020c\_005

**PAGE** **D-43**


## Powertrain Controls (Diesel LLY V8)



# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-44

## Powertrain Controls (Diesel LLY V8)



E 35 C-SAMPLE WILL HAVE ALL SILVER PLATED PINS. PLATFORM TO ENSURE THAT ALL MATING PINS FOR THE C-SAMPLE ARE SILVER PLATED

C-SAMPLE WILL BE AVAILABLE 2ND WEEK OF APRIL

Powertrain Controls (diesel Lly V8)  
GMT610 06 G\_Van  
Panel Set: 12 schematic sheet1 \$ 19

OBJECT ID  
826020c

REVISION  
005

STAGE  
X

VERSION  
LAST CHANGED BY

Tuesday, September 14, 2004


ORGANIZATION  
GMT610

6:56:54 pm

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-45

## Powertrain Controls (Diesel LLY V8)



Powertrain Controls (diesel Lly V8)

GMT610 06 G\_Van  
Panel Set: 13 schematic sheet1

OBJECT ID  
826020c

SIVEDWORK/826020c\_005

REVISION  
005

STAGE  
X

VERSION  
0

LAST CHANGED BY  
Tuesday, September 14, 2004

ORGANIZATION  
GMT610

6:56:54 pm Panel Set: 13

**PAGE** **D-46**


The diagram illustrates the electrical system for the fuel pump and fuel injectors. It shows the power source (PWR TRN) connected to the fuel pump relay (FUEL PMP RLY) and the fuel pump sensor (FUEL PMP SENS). The fuel pump relay is controlled by the engine control module (ECM) and the fuel pump sensor. The fuel pump sensor is connected to the fuel pump relay and the fuel pump. The fuel pump is connected to the fuel injectors. The diagram also shows the fuel tank vacuum sensor (FUEL TANK VACUUM SEN) and the fuel pump sender (FUEL PMP SENDER) connected to the fuel pump. The fuel pump sender is connected to the fuel pump and the fuel pump sensor. The fuel pump sensor is connected to the fuel pump relay and the fuel pump. The fuel pump relay is connected to the engine control module (ECM) and the fuel pump. The fuel pump is connected to the fuel injectors. The diagram is a technical drawing with a white background and black lines and text.

| Fuel         | REVISION  | STAGE  | VERSION | LAST CHANGED BY       | ORGANIZATION |
|--------------|-----------|--------|---------|-----------------------|--------------|
| GMT610       | 06 G. Van | 002    | X       | GMT610                | GMT610       |
| Panel Set: 1 | schematic | sheet1 | 9       | SIVEDWORK/826022a_002 | 3:52:29 pm   |


**PAGE** **D-47**

**PAGE** **D-48**

### ***LCT Transmission (LLY & T42)***



## Charging & Energy Storage (BASE)



2-A-1

Charging & Energy Storage (BASE)

GMT610  
Panel Set: 1

06 G\_Van  
schematic sheet1

OBJECT ID  
826030a

8

SIVEDWORK/826030a\_004

REVISION  
004

STAGE  
X

VERSION  
0

LAST CHANGED BY  
Monday, August 2, 2004


ORGANIZATION  
GMT610

1:01:05 pm  
Panel Set: 1

# 2006 & 2007 G/H Full-Size Van Electrical


PAGE D-50

## Charging & Energy Storage (LLY DIESEL)




## Stepper Motor Cruise Control (SMCC)

**NOTE:**  
FOR SEO 9B9/9D4, THE  
ROAD SPEED GOVERNOR KIT WILL  
CONNECT TO THE CRUISE CONTROL  
CONNECTOR ON IP HARNESS



Horns



**PAGE** **D-53**

[illegible]

**PAGE** **D-54**

Wiring diagram for Vses W/ ABS system. The diagram shows a central VSES (Vehicle Speed Sensor) unit connected to various components. On the left, there are fuses for (BBEC) VSES, (UHBEC) ABS, and (POWERTRAIN) Pcm. These connect to terminals J1-B, J1-F, J1-14, J1-15, J1-11, and J1-4. A wheel speed sensor (WHEEL SPEED SENSOR) is connected to J1-33 and J1-34. On the right, another wheel speed sensor is connected to J1-35 and J1-36. The VSES unit also connects to a fluid level switch (J1-31) and a brake fluid level switch (15749468). A 10A fuse is connected to the VSES unit. The diagram includes a detailed view of the VSES unit showing its internal components and connections. The bottom of the diagram contains a table with revision information and a date stamp.

| REVISION | STAGE | VERSION | LAST CHANGED BY | 9:52:48 am | ORGANIZATION |
|----------|-------|---------|-----------------|------------|--------------|
| 002      | X     |         |                 |            |              |


Thursday, March 18, 2004

GMT610  
Panel Set: 1

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-55

## Vses W/ ABS



### Vses W/ ABS

GMT610 06 G\_Van  
Panel Set: 2 schematic sheet1

OBJECT ID  
826044b

12

SIVEDWORK/826044b\_002

REVISION STAGE VERSION LAST CHANGED BY  
002 X

Thursday, March 18, 2004


9:52:48 am

ORGANIZATION  
GMT610  
Panel Set: 2

# 2006 & 2007 G/H Full-Size Van ELECTRICAL

PAGE D-56


## Vses W/ ABS



# 2006 & 2007 G/H Full-Size Van ELECTRICAL

PAGE D-57

## Vses W/ ABS



Vses W/ ABS

GMT610 06 G, Van  
Panel Set: 4 schematic sheet1

OBJECT ID  
826044b

IVEDWORK/826044b\_002


REVISION STAGE VERSION  
002 X

LAST CHANGED BY  
Thursday, March 18, 2004

9:52:48 am

ORGANIZATION  
GMT610  
Panel Set: 4

## Occupant Protection



Occupant Protection  
 GMT610 06 G. Van  
 Panel Set: 1 schematic sheet1

OBJECT ID  
 826047a


REVISION  
 002

STAGE  
 X

VERSION  
 LAST CHANGED BY  
 Tuesday, December 2, 2003

ORGANIZATION  
 GMT610  
 Panel Set: 1

## Occupant Protection



Occupant Protection

GMT610 06 G\_Van  
 Panel Set: 2 schematic sheet1

OBJECT ID  
 826047a

25

SIVEDWORK/826047a\_002

REVISION  
 002

STAGE  
 X

LAST CHANGED BY  
 Tuesday, December 2, 2003

ORGANIZATION  
 GMT610  
 Panel Set: 2


7:27:43 am

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-60

## Occupant Protection

See note below <----- Sdm  
15730630  
15449363



### NOTE:

#### CONNECTOR

P/N RETAINER CONNECTOR

|          |          |          |
|----------|----------|----------|
| 15750630 | 15417909 | 15449363 |
| 15750631 | 15417908 | 15449363 |
| 15750634 | 15417909 | 15449363 |
| 15750635 | 15417908 | 15449363 |

Occupant Protection

GMT610 06 G\_Van  
Panel Set: 3 schematic sheet1 \$ 25

OBJECT ID  
826047a

IVEDWORK/826047a\_002

REVISION  
002

STAGE  
X

VERSION  
LAST CHANGED BY

Tuesday, December 2, 2003

ORGANIZATION  
GMT610

7:27:43 am Panel Set: 3

**PAGE** **D-61**

[illegible]

**PAGE** **D-62**

**Serial Data (Class 2)**


| OBJECT ID | REVISION | STAGE | VERSION | LAST CHANGED BY | ORGANIZATION |
|-----------|----------|-------|---------|-----------------|--------------|
| GMT610    | 003      | X     |         |                 | GMT610       |

Panel Set: 1 schematic sheet1 \$ 8 IVDWORK\826050a\_003 Tuesday, September 14, 2004 2:06:35 pm Panel Set: 1

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-63

## Serial Data (Class 2)



**GAS/DIESEL ENGINE**

Serial Data (Class 2)

GMT610 06 G\_Van  
Panel Set: 2 schematic sheet1

OBJECT ID  
826050a

IVEDWORK/826050a\_003

REVISION  
003

STAGE  
X

VERSION LAST CHANGED BY

Tuesday, September 14, 2004

ORGANIZATION

GMT610

Panel Set: 2

2:06:35 pm

**PAGE** **D-64**

[illegible]

**PAGE** **D-65**


[illegible]

Panel Set: 2

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-66

## Heating & Cooling (HVAC)



Heating & Cooling (HVAC)

GMT610  
 Panel Set: 1

OBJECT ID  
 826065a

REVISION  
 004

STAGE  
 X

VERSION  
 LAST CHANGED BY

Tuesday, September 14, 2004


ORGANIZATION  
 GMT610

Panel Set: 1

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-67


## Heating & Cooling (HVAC)



# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-68

## Heating & Cooling (HVAC)



Heating & Cooling (HVAC)

GMT610  
Panel Set: 3

06 G\_Van  
schematic

sheet1

\$ 25

OBJECT ID  
826065a

IVEDWORK/826065a\_004

REVISION  
004

STAGE  
X

VERSION  
LAST CHANGED BY

Tuesday, September 14, 2004

ORGANIZATION  
GMT610

6:58:27 pm  
Panel Set: 3

**PAGE** **D-69**

REAR HVAC MODULE

NOTE:  
101 = &C36-C69 (HEAT SW)  
102 = &YF7-C36/C69 (FAN SW)


| Heating & Cooling (HVAC)                             | OBJECT ID | REVISION | STAGE | VERSION | LAST CHANGED BY | ORGANIZATION |
|------------------------------------------------------|-----------|----------|-------|---------|-----------------|--------------|
| GMT610<br>06 G. Van<br>Panel Set: 4 schematic sheet1 | 826065a   | 004      | X     |         |                 | GMT610       |

Tuesday, September 14, 2004 5:58:27 pm Panel Set: 4

# 2006 & 2007 G/H Full-Size Van ELECTRICAL

PAGE D-70

## Heating & Cooling (HVAC)



Heating & Cooling (HVAC)

GMT610 06 G\_Van  
Panel Set: 5 schematic sheet1

OBJECT ID  
826065a

25

SIVEDWORK/826065a\_004

REVISION  
004

STAGE  
X

VERSION  
LAST CHANGED BY

Tuesday, September 14, 2004







ORGANIZATION  
GMT610

6:58:27 pm

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-71

## Heating & Cooling (HVAC)



Heating & Cooling (HVAC)

GMT610 06 G\_Van

Panel Set: 6 schematic sheet1

OBJECT ID  
826065a

25

SIVEDWORK/826065a\_004

REVISION  
004

STAGE  
X

VERSION  
0

LAST CHANGED BY

Tuesday, September 14, 2004


ORGANIZATION  
GMT610

6:58:27 pm Panel Set: 6

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-72

## Instrument Panel Cluster (Displays)



Instrument Panel Cluster (Displays)

GMT610 06 G\_Van  
Panel Set: 1 schematic sheet1

OBJECT ID  
826081a

IVEDWORK/826081a\_002


REVISION  
002

STAGE  
X

VERSION  
LAST CHANGED BY  
Tuesday, December 2, 2003

ORGANIZATION  
GMT610  
Panel Set: 1

Wipers



**PAGE** **D-74**

|      |      |
|------|------|
| PAGE | D-75 |
|------|------|

[illegible]


**PAGE** **D-76**

[illegible]

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-77

## Power Windows



Power Windows

GMT610  
Panel Set: 1

OBJECT ID  
826120a

06 G\_Van

sheet1

3

SIVEDWORK/826120a\_002

REVISION  
002

STAGE  
X

VERSION  
LAST CHANGED BY

Tuesday, December 2, 2003


ORGANIZATION  
GMT610

Panel Set: 1

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-78

## Entry Control




|      |      |
|------|------|
| PAGE | D-79 |
|------|------|

| Entry Control | OBJECT ID                 | REVISION | STAGE | VERSION | LAST CHANGED BY | ORGANIZATION |
|---------------|---------------------------|----------|-------|---------|-----------------|--------------|
| GMT610        | 826130a                   | 002      | X     |         |                 | GMT610       |
| Panel Set: 2  | 06 G. Van                 | 002      | X     |         |                 | GMT610       |
| schematic     | sheet1                    | 3        |       |         |                 | GMT610       |
|               | SIVEDWORK/826130a_002     |          |       |         |                 | GMT610       |
|               | Tuesday, December 2, 2003 |          |       |         |                 | GMT610       |
|               | 8:09:09 am                |          |       |         |                 | GMT610       |
|               | Panel Set: 2              |          |       |         |                 | GMT610       |

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-80

## Power Seats



Power Seats

GMT610

Panel Set: 1

06 G\_Van

schematic

sheet1

\$ 12

OBJECT ID  
826143a

IVEDWORK/826143a\_002

REVISION  
002

STAGE  
X

VERSION  
LAST CHANGED BY

Tuesday, December 2, 2003

ORGANIZATION  
GMT610

8:10:19 am

Panel Set: 1

**PAGE** **D-81**

[illegible]

|             |             |
|-------------|-------------|
| <b>PAGE</b> | <b>D-82</b> |
|-------------|-------------|

**Mirrors**  
GMT610  
Panel Set: 2

**OBJECT ID**  
826147a

**REVISION**  
002

**STAGE**  
X

**VERSION**  
LAST CHANGED BY

**ORGANIZATION**  
GMT610  
Panel Set: 2


06 G. Van  
sheet1  
\$ 3  
IVEDWORK/826147a\_002  
Tuesday, December 2, 2003  
8:11:42 am

|             |             |
|-------------|-------------|
| <b>PAGE</b> | <b>D-83</b> |
|-------------|-------------|

[illegible]

**PAGE** **D-84**


RADIO PART # 15756190 = UPLEVEL RADIO W/ RDS, CASSETTE & CD. (UB1)  
RADIO PART # 15756191 = UPELEVEL RADIO W/RDS, CASSETTE & CD (EXPORT) (UB1)  
RADIO PART # 15756192 = UPELEVEL RADIO W/ RDS & 6 CDXR (UC6)  
RADIO PART # 15756193 = UPELEVEL RADIO W/RDS & 6 CDXR (EXPORT) (UC6)  
RADIO PART # 15756185 = BASE RADIO (UM7)  
RADIO PART # 15756187 = BASE RADIO W/ CD (UIC)  
ALARM PART # 15750622 = CHIME MODULE (UL5 RADIO DELETE OPTION)



# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-85


## Audio (Speakers)



# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-86

## Steering Column Controls (Stalk Switch)



**PAGE** **D-87**


# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-88

## Special Equipment Options – 5G4 – Roof Mounted Lamp

SEO - 5G4

ROOF MOUNTED LAMP



Special Equipment Options  
GMT610 06 G\_Van  
Panel Set: 1 schematic sheet1

OBJECT ID  
826260a

REVISION  
002

STAGE  
X

VERSION  
LAST CHANGED BY  
Tuesday, December 2, 2003

ORGANIZATION  
GMT610  
Panel Set: 1


Special Equipment Options

INTENTIONALLY LEFT BLANK

**PAGE** **D-90**

**SEO - 8A2**

**DUAL BATTERIES**



**\* NOTE:**  
**Fuselink 8.0 = BLK**


| Special Equipment Options |           |        | OBJECT ID | REVISION              | STAGE | VERSION | LAST CHANGED BY           | ORGANIZATION | 50 RING TERM<br>(GND DIST) |
|---------------------------|-----------|--------|-----------|-----------------------|-------|---------|---------------------------|--------------|----------------------------|
| GMT610 06 G_Van           |           |        | 826260a   | 002                   | X     |         |                           | GMT610       |                            |
| Panel Set: 3              | schematic | sheet1 | 3         | SIVEDWORK/826260a_002 |       |         | Tuesday, December 2, 2003 | 8:18:32 am   | Panel Set: 3               |

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-91

## Special Equipment Options – 8J0 – Cooling Fan

SEO - 8J0  
COOLING FAN



Special Equipment Options  
GMT610 06 G\_Van  
Panel Set: 4 schematic sheet1 \$ 3

OBJECT ID  
826260a

REVISION  
002

STAGE  
X

VERSION  
LAST CHANGED BY  
Tuesday, December 2, 2003

ORGANIZATION  
GMT610  
Panel Set: 4


# 2006 & 2007 G/H Full-Size Van ELECTRICAL

PAGE D-92

## Special Equipment Options – 8S3 – Backup Alarm

SEO - 8S3

BACK-UP ALARM



Special Equipment Options  
GMT610 06 G\_Van  
Panel Set: 5 schematic sheet1 \$ 3

OBJECT ID  
826260a

REVISION  
002

STAGE  
X

VERSION

LAST CHANGED BY  
Tuesday, December 2, 2003

ORGANIZATION  
GMT610  
Panel Set: 5


# 2006 & 2007 G/H Full-Size Van ELECTRICAL

PAGE D-93

## Special Equipment Options – 8S8 – Odo Security

SEO - 8S8

ODO SECURITY



Special Equipment Options  
GMT610 06 G, Van  
Panel Set: 6 schematic sheet1 \$ 3

OBJECT ID  
826260a

REVISION  
002

STAGE  
X

VERSION  
LAST CHANGED BY

Tuesday, December 2, 2003

ORGANIZATION  
GMT610

8:18:32 am Panel Set: 6

IVEDWORK/826260a\_002

# 2006 & 2007 G/H Full-Size Van Electrical


PAGE D-94

## Special Equipment Options – 9B9, 9B4 – Road Speed Governor

SEO - 9B9, 9D4  
ROAD SPEED  
GOVERNOR

### NON-INTELLIGENT

FOR REFERENCE ONLY. WILL RELEASE EXISTING IP HARNESS WITH  
K34 - SEE CRUISE CONTROL MECH.



Special Equipment Options  
GMT610 06 G\_Van  
Panel Set: 7 schematic sheet1 \$ 3

OBJECT ID  
826260a

REVISION  
002

STAGE  
X

VERSION  
LAST CHANGED BY

Tuesday, December 2, 2003

ORGANIZATION  
GMT610  
Panel Set: 7

8:18:32 am


# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-95

## Special Equipment Options – 9L0 – Computer Screen Blanking

SEO - 9L0

COMPUTER SCREEN BLANKING



Special Equipment Options  
GMT610 06 G, Van  
Panel Set: 8 schematic sheet1 \$ 3

OBJECT ID  
826260a

REVISION  
002

STAGE  
X

VERSION  
LAST CHANGED BY

Tuesday, December 2, 2003

ORGANIZATION  
GMT610


8:18:32 am Panel Set: 8

IVEDWORK/826260a\_002

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-96

## Special Equipment Options – &9L4 – Mobile Radio



**PAGE** **D-97**

The diagram is a detailed wiring schematic for a vehicle's master system, organized into several functional sections:


- Powertrain Controls (v6 Pcm) 826020a 002 &LU3**: This section shows the wiring for the Powertrain Control Module (PCM) and its associated components, including various sensors and actuators.
- Powertrain Controls (diesel LI) 826020c 005**: This section shows the wiring for the diesel engine's Powertrain Control Module and its associated components.
- Electronic Throttle Control 826021a 002 &KUP**: This section shows the wiring for the Electronic Throttle Control (ETC) system, including the throttle body and the throttle position sensor.
- Fuel 826022a 002**: This section shows the wiring for the fuel system, including the fuel pump, fuel injectors, and the fuel pressure sensor.
- Lct Transmission (Ily&T42) 826027a 004**: This section shows the wiring for the transmission control system, including the transmission range sensor and the transmission oil pressure sensor.
- Charging & Energy Storage (BASE) 826030a 004**: This section shows the wiring for the base charging and energy storage system, including the battery and the charging system.
- Charging & Energy Storage (LLY DIESEL) 826030b 003**: This section shows the wiring for the LLY diesel engine's charging and energy storage system, including the battery and the charging system.
- Ground Distribution 826014a 004**: This section shows the wiring for the ground distribution system, including the ground points and the ground wires.
- Power Moding 826010b 002**: This section shows the wiring for the power moding system, including the power moding switch and the power moding relay.
- Power Distribution (Body BEC) 826010c 004**: This section shows the wiring for the power distribution system, including the power distribution switch and the power distribution relay.

The diagram includes numerous labels for components and their connections, organized into several distinct sections. The labels are arranged in a way that makes it easy to identify the components and their connections. The diagram is a complex wiring schematic for a vehicle's master system, showing various components like Powertrain Controls, Fuel, Lct Transmission, Charging & Energy Storage, and Ground Distribution. The diagram includes numerous labels for components and their connections, organized into several distinct sections.

# 2006 & 2007 G/H Full-Size Van Electrical

PAGE D-98

## Master System



**PAGE** **D-99**

|                                                       |                                                  |
|-------------------------------------------------------|--------------------------------------------------|
| <p>Audio (Speakers)<br/>826150a 002</p>               | <p>Special Equipment Options<br/>826260a 002</p> |
| <p>Audio (Speakers)<br/>826150b 002</p>               |                                                  |
| <p>Steering Column Controls (Stal<br/>826155a 002</p> |                                                  |
| <p>Entertainment (Onstar)<br/>826160a 002</p>         |                                                  |